

CCPJ-3020W Horizontal Projector



Usage:

CCPJ-3020W Ø300mm horizontal projector is photoelectric measuring system of high precision and efficiency. This instrument can inspect all kinds of surface and outline of complicated work-pieces, cam, screw thread, gear, perform milling cutter and so on. It is widely used in machinery, metal, ironware, electrical, light industry, data can output and print.

Specification:

Working table	Working table's size(mm)	400*150
	X-axis travel(mm)	200
	Z-axis travel(mm)	100
	Y-axis travel(mm)	75 focus
	Turning range	±15°
	Resolution(X-axis,Z-axis)	0.001mm
	The indication error of coordinate(μm)	≤(3+L/200)
Dimension	L*W*H(mm)	1090*830*1010
Weight	Unit:(kg)	200
Projector screen	Screen size(mm)	Ø300

	Screen rotary range	0°~360°			
	Rotary angle Resolution	1' or 0.01°			
Lens	Lens Multiple	10X(option)	20X(option)	50X(option)	100X(option)
	Object view(mm)	Ø30	Ø15	Ø6	Ø3
	Working distance(mm)	77.7	44.3	38.4	25.3
Data processing system	DC-3000 multi-function data processing system ,can realize the transition of English and Chinese ,it can be used to gather the data and measure the point ,line, circle, angle and distance				
Illumination	24V/150V halogen transmitted illumination for the launch of 21V/150W halogen lighting, etc. (with illumination light)				
Power	110V/220V(AC);50/60HZ; Total power: 400W				
Option	Mini-printer, Edge detector,M2D software and so on				